

LCD thermometer

for buried and surface installation

Art. Nr.: 0074 ..

Function

The LCD thermometer is used to take the room temperature.

Installation site

Install the LCD thermometer only in closed rooms.

In order to avoid damage and **inaccurate reading**, you should not expose the thermometer to high humidity, **extreme temperature** (in combination with a dimmer for example), vibration and shock.

Danger warning and instruction for disposal

Warning! Keep button cells off children. Immediately consult a doctor if your child swallowed a button cell.

Immediately remove exhausted battery and dispose of it environmentally friendly. Replace battery only with identical type.

This product shall not be used for medical purposes or to inform the public.

Replacement of battery

The battery should be replaced at least once a year for optimum indicating accuracy. Instructions for replacement:

1. Turn the cover of the battery compartment counterclockwise using a coin or a similar object.
2. Open the compartment, remove the battery and wait at least 10 sec.
3. Replace the exhausted battery with a new one of the same type (LR44/1,5 V). Take care to use the correct polarity.
4. Reinsert the cover of the battery compartment and close it by turning it clockwise.

Care

Clean the display and case only with a soft, slightly wetted cloth. Do not use abrasives or solvents. Do not dip case into water.

Specifications

Display:	LCD display
Temperature range:	-5°C ... +50°C
Resolution:	0.1°C
Voltage supply:	battery type LR44 / 1.5V
Measuring accuracy:	± 1°C

Acceptance of guarantee

We accept the guarantee in accordance with the corresponding legal provisions.

Please return the unit postage paid to our central service department giving a brief description of the fault:

Gira
Giersiepen GmbH & Co. KG
Service Center
Dahlienstrasse 12
D-42477 Radevormwald



The CE sign is a free trade sign addressed exclusively to the authorities and does not include any warranty of any properties.

Gira
Giersiepen GmbH & Co. KG
Postfach 1220
D-42461 Radevormwald

Telefon: +49 / 21 95 / 602 - 0
Telefax: +49 / 21 95 / 602 - 339
Internet: www.gira.de